

Mash Liquefaction

SIHA® Distillery Enzyme SK Plus



SIHA Distillery Enzyme SK Plus from Eaton's Begerow Product Line is a new, highly effective enzyme preparation for the optimization of mash liquefaction. The resulting increase in surface area enables the yeasts to quickly reach high final attenuation. Complete mash disintegration promotes maximum alcohol yield and flavor release.

The specific advantages of SIHA Distillery Enzyme SK Plus:

- High-performance preparation with optimum enzyme activity
- Promotes maximum possible mash liquefaction

Complete mash disintegration leads to:

- Fruit mashes that are better pumpable and fermentable
- Rapid pre-fermentation and safe end fermentation
- More aromatic fermentation for high-quality distillates
- High final attenuation and increased yield
- Better cost effectiveness
- Increased flavor release
- Reduction of the natural methanol content
- Simple system cleaning

Application

SIHA Distillery Enzyme SK Plus has to be in intense contact with the mash to be disintegrated. We therefore recommend adding the enzyme continuously during mashing. Complete distribution in the fermentation vessel ensures maximum mash disintegration. Mixing through pumping and stirring is advantageous.

The most effective temperature range for the enzyme application is 59 – 104 °F (15 – 40 °C). If the mash temperature is below 59 °F (15 °C), the quantities should be increased by approximately 50%.

Application	Fermentation temperature in °F (°C)	Dosage fl dr/100 lb (ml/100 kg)
Apple mash	54 – 86 (12 – 30)	0.74 – 0.98 (6 – 8)
Pear mash	54 – 86 (12 – 30)	0.49 – 0.61 (4 – 5)
Plum mash	54 – 86 (12 – 30)	0.24 – 0.37 (2 – 3)
Jerusalem artichoke mash	54 – 86 (12 – 30)	1.84 – 2.45 (15 – 20)

Safety

When used and handled correctly, there are no known unfavorable effects associated with SIHA Distillery Enzyme SK Plus.

Further safety information can be found in the relevant Material Safety Data Sheet, which can be downloaded from our website.

Storage

SIHA Distillery Enzyme SK Plus is delivered in convenient polythene bottles with reclosable screw cap.

SIHA Distillery Enzyme SK Plus should be stored in a cool and dry place. At a storage temperature of 68 °F (20 °C), it remains fully active for three months; subsequently, activity is expected to drop by 1 – 2% per month.

Delivery Information

SIHA Distillery Enzyme SK Plus is sold under article no. 95.056 and is available in the following package size:

0.26 gal (1 l) PE bottle

HS Customs Tariff: 3507 90 90

Certified Quality

During the production process, SIHA Distillery Enzyme SK Plus is constantly monitored to ensure consistently high quality. These inspections cover technical function criteria as well as conformance with the relevant laws governing the production and sale of foodstuffs. Strict controls are carried out immediately before and during final packaging.

North America - HQ

44 Apple Street,
Tinton Falls, NJ 07724
Toll Free: 800 656-3344
(North America Only)
Voice: +1 732 212-4700

Europe/Africa/Middle East

Auf der Heide 2
53947 Nettersheim, Germany
Voice: +49 2486 809-0

Internormen Product Line

Friedensstraße 41
68804 Altlussheim, Germany
Voice: +49 6205 2094-0

Begerow Product Line

An den Nahewiesen 24
55450 Langenlonsheim, Germany
Voice: +49 6704 204-0

Brazil

Av. Julia Gaioli, 474 - Bonsucesso
07251-500 - Guarulhos
Brazil
Voice: +55 11 2465 8822

China

No. 7 Lane 280 Linhong Road,
Changning District,
Shanghai 200335, China
Voice: +86 21 5200 0422

Singapore

4 Loyang Lane #04-01/02
Singapore 508914
Voice: +65 6825 1668

For more information, please e-mail us at filtration@eaton.com or visit us online at eaton.com/filtration for a complete list of Eaton's filtration products.

Not all products in Eaton's Begerow Product Line are available in all regions. Please contact your local Eaton office to determine availability.

© 2013 Eaton Corporation. All Rights Reserved. All trademarks and registered trademarks are the property of their respective owners.

All information and recommendations appearing in this brochure concerning the use of products described herein are based on tests believed to be reliable. However, it is the user's responsibility to determine the suitability for his own use of such products. Since the actual use by others is beyond our control, no guarantee, expressed or implied, is made by Eaton as to the effects of such use or the results to be obtained. Eaton assumes no liability arising out of the use by others of such products. Nor is the information herein to be construed as absolutely complete, since additional information may be necessary or desirable when particular or exceptional conditions or circumstances exist or because of applicable laws or government regulations.